Southwestern Industries, Inc

TRAK VMC7 Specifications with the ProtoTRAK RMX Control



Machine Specifications

- Table Size 35.43" x 19.69"
- T-slots (number x width x pitch) 5 x .709" x 3.937"
- Travel (X, Y, Z axis) w/ Soft Limits 30" x 20" x 20"
- Spindle Taper 40 Taper
- Spindle Speed Range (RPM) 50 8,000 RPM
- Spindle Nose Diameter 3"
- Tool Clamping Force (90 psi) 1,500 lbs
- Tool Holder Type CAT 40 or BT 40
- ATC Tool Capacity 16
- Maximum Tool Weight (incl. holder) 15 lbs
- Maximum Tool Diameter 3.14"
- Carousel Speed .8 sec from station to station
- Tool Selection System bi-directional/shortest path
- Spindle Motor HP (peak) 15 HP
- Spindle Motor HP (continuous) 10 HP

Specifications subject to change.

*** Height changes slightly based on how machine is leveled on leveling screws.

^{****} Can vary slightly due to home switch location and soft limit settings.

- Power Requirements (standard) 208V (200-240V is acceptable), 3P, 67.3A
- Power Requirements (optional) 480V w/ transformer option (432-528V is acceptable), 3P, 36A
- Maximum Weight of Workpiece 1,000 lbs
- Height of Table from Bottom of Bed*** 38"
- Min. Spindle Nose to Table Distance**** 3.5"
- Max. Spindle Nose to Table Distance**** 23.5"
- Distance of Tool Carousel to Table 17.5"
- Spindle Center to Spindle Head Casting Face 18.25"
- Min. Machine Height*** 90"
- Max. Machine Height (head all the way up)*** 106.50"
- Overall Width of Machine (w/ side doors open, auger chute, and chip container in place) 167.25"
- Overall Length of Machine (w/ electrical cabinet fully open 180°) 152"
- Footprint of Machine w/ Coolant Tank in Place & Pendant Rotated 90° (w x l) − 97" x 135"
- Weight Net 8,360 lbs.
- Weight Ship 8,710 lbs.
- Rapid Traverse X, Y, Z 400 IPM in Toolroom Ops, 1,000 IPM in Production Ops
- Coolant Capacity 56 gal
- Coolant Pump & Wash Power 750 Watt
- Air Pressure 90 PSI 2.5 CFM, or 18 at 90 PSI SCFM
- Air Quality Air dried/water separator upstream of VMC
- Lubrication Pump Capacity 2 liter

Options

- Electronic Handwheels
- Offline Programming
- Remote Stop/Go Switch
- Vise Kit
- Tool Measurement Cart
- Internal Memory Drive
- Transformer Option
- Gripper BT 40 Tooling
- Retention Knobs Cat 40 Tooling
- Auxiliary Functions

ProtoTRAK RMX System Specifications

Software Features – General Option

- Enhanced ProtoTRAK Assistance (EPA)
 - Context responsive help with control operations
 - Step-by-step instructions, diagrams and videos
- Watch Me videos for quick introduction to ProtoTRAK RMX operation
- What's New videos for quick review of upgraded features in new releases
- Clear, uncluttered screen display
- Fly out windows for quick access to features and info
- Programming Defaults to simplify part programming
- User profiles for Defaults
- Event Options to modify Defaults or select additional functionality
- QWERTY touchscreen keyboard
- Calculator
- Prompted data inputs
- English language no codes

Specifications subject to change.

*** Height changes slightly based on how machine is leveled on leveling screws.

**** Can vary slightly due to home switch location and soft limit settings.

- Soft keys change within context
- Windows[®] operating system
- Selectable two or three-axis CNC
- Color graphics with adjustable view
- Gestures for pan, zoom, rotate
- Inch/mm conversion
- Convenient modes of operation
- Networking

DRO Mode Features

- Incremental and Absolute dimensions
- Graphical Override of Axis Feed and Spindle RPM
- Jog at rapid with override
- Power feed X, Y or Z
- Teach-in of manual moves
- Programmable Go To dimensions
- Servo return to 0 absolute
- Tool offsets from Tool Library
- Line Center calculation
- Circle Center calculation

Program Mode Features

- Circular interpolation
- Linear interpolation
- Advanced Adaptive Tool Path
- Geometry programming
- Toolpath programming
- Auto Geometry Engine® (A.G.E.) Built-in CAD to fill in missing print data
- Alphanumeric program names
- Automatic Scaling of print data
- Nesting
- Multiple Fixtures
- Incremental and absolute dimensions may be mixed on a single point
- Automatic diameter cutter comp
- Program data editing
- Part graphics update while programming
- Selectable display between size of drawing and number of events
- List Step graphics relate Events to Drawing
- Editing of programmed data
- Swipe to move through programmed Events

Canned Cycles (Event Types)

- Position
- Drill/Bore/Tap/Helical Drill
- Bolt Hole Drill/Bore/Tap/Helical Drill
- Mill
- Arc
- Circular Profile
- Rectangular Profile
- Irregular Profile (with Auto Geometry Engine)
- Face Mill

Specifications subject to change.

*** Height changes slightly based on how machine is leveled on leveling screws.

**** Can vary slightly due to home switch location and soft limit settings.

- Circle Pocket/Rectangular pocket •
- Irregular Pocket (with Auto Geometry Engine) •
- Islands including Pocket and Island shapes
- Subroutine Repeat/Mirror/Rotate
- Subroutine Convert Drill to Tap
- Copy Mirror/Rotate/Convert Drill to Tap •
- Helix •
- Engrave Horizontal/Radial/Vertical/Mirror •
- Thread Mill •
- **Program Pause**

Advanced Features

- Adaptive Pocket Roughing
- Verify Make Part solid model simulation of programmed toolpath •
- Finish Tool #
- Rest Machining •
- Multiple Fixture Offsets •
- **Event Comments** •
- G-code editor
- Search Edit •
- Tool Library Flyout Window •
- Automatic Tool Syncing between carousel, program and library tools
- Pictures and notes saved in Part Programs •
- Save and Open Temp •
- Program I/O Look •
- Chip Clear
- Clipboard

DXF File Converter Option

- Import/convert CAD data into ProtoTRAK programs •
- DXF or DWG files
- Chaining
- Add or remove geometry
- Automatic Gap Closing •
- Layer control
- Easy, prompted process right at the machine
- Island and Profile Events

Parasolid File Converter Option

- Import and convert 2.5D CAD data into ProtoTRAK programs
- X T files •
- X, Y and Z dimensions are transferred into program events
- 2D and 3D views of part
- Chaining
- Add or remove geometry •
- Easy, prompted process you can do right at the machine •
- Island and Profile Events

Specifications subject to change.

*** Height changes slightly based on how machine is leveled on leveling screws.